



PMX SYSTEM - MUSIC SERVER



Among the windows available in PMX System : Group Setup, Main Window, Play Message, Play Panel and Test.

INTERFACING SCHEMATIC -



Introducing the upgraded Amperes PMX System, a software based product which is a sort of integration of various hardware components such as programmable timer, chime & siren tone generator, message recorder / player, CD player, music bank and paging station.

With PMX System, a significant amount is saved from investing in hardwares, less maintenance and moreover, it is easily upgraded from time to time, making it a product that never obsolete.

It can be easily installed in any standard PC (see requirement), interface it with USB to RS485 converter (provided) for zone selection capability, or use it merely as a music bank, link the audio and control output to existing PA installation, and you shall get an enhanced system.

It is suitable for offices, public transportation stations, shopping malls, hotels, factories, schools etc, where daily repetitive announcement is required.

FEATURES -

MEDIA PLAYBACK

Plays audio CD, MP3, WAV and other formats compatible with Window media player from stored files, USB or through CD.

MUSIC / MESSAGE / TONE STORAGE

Stores unlimited songs, messages, tones or chimes in PC HDD for playback with just clicks away.

WEEKLY PROGRAMMABLE TIMER

Allows repetitive playback of tone or message such as chime for lunch breaks, morning calls, welcome greeting for work shift, etc.

SCHEDULED ACTIVATION

Scheduled broadcast such as birthday song can be programmed with zone assignment.

ZONE CONFIGURATION

Zones can be named and grouped and assignable as Normal or Emergency zone for privacy and convenience of paging.

BROADCAST ZONE ASSIGNMENT

Schedule paging, music playback can be assigned to certain zones instead of blanket ALL CALL broadcast.

CONVENIENT INTEGRATION TO EXISTING SYSTEM

PMX can be easily integrated to existing installation for system enhancement.

SECURITY PROTECTION

Admin and user levels with password avoids unnecessary tampering to the system setup.

UPGRADES

System upgrades and free downloads shall be available free. Future upgrades includes interfacing with BAS system, etc.

PACKAGE INCLUDES :

- Software CD
- USB to RS485 converter / Audio converter for interfacing with Amperes TD6240 decoder for zone selector activation

HARDWARE REQUIREMENTS

- PC with Window XP operating system ; Pentium 4 and above, 512 MB RAM and Monitor

FOR ZONE ACTIVATION

- Amperes TD6240 decoder
- Amperes ZS5601 / 5121 / 5602 zone selectors



PMX 6500

USB - RS485 converter / Audio Converter